

FIG. 2 50 -60 10 12 11 52 BAR CODE **-65** TRANS-PRESSURE SENSOR PRESSURE MONITOR ECU RUNNING STATE RECE I VER -70 DISPLAY PRESSURE SENSOR TRANS-MITTER **RECEIVER** 20 22 21

FIG. 3



